

# Simple Solutions




**Rackmatic®** – one step adjustment for up to 9 rack positions — fits taller items like stemware in the middle rack while leaving room for pots and pans below

**FlexSpace™ Tines** – fold down every other tine in one simple step, making room for larger, bulkier items



**EasyGlide™ wheels** – smooth-rolling ball bearings deliver racks with an effortless glide — even when the rack is fully loaded

**3<sup>rd</sup> Racks** – three 3<sup>rd</sup> rack options provide additional loading space and flexibility to load large utensils and small dishes



## Conveniently Reorder Products

- Set up directly through the **Amazon Alexa** app  
*Activate dishwasher skill > Set up reorders*
- **Home Connect™** tracks detergent tab inventory with each cycle
- When inventory is low, additional tablets will be ordered through **Amazon Smart Reorder**
- Once package is delivered, the ordered quantity is added back into the tablet counter

