## **Bosch 3rd Rack Competitive Comparison**



\* Use & Care manual states "The 3<sup>rd</sup> rack horizontally positions knives, spatulas and other oversized tools for improved cleaning and easier loading and unloading." **Feel free to place heavily soiled items on any of the Bosch racks including the 3<sup>rd</sup> rack!** 

Bosch	Feature	Brand "XL"
$\checkmark$	Solid One Piece Design	
√	Deep "V" Design for Large Utensils	
✓	Allows 30% More Loading Area	
✓	Allows 6" Plate at Highest Setting	
$\checkmark$	Flexibility / Easily Removed	
$\checkmark$	Silverware Basket Included	$\checkmark$
✓	3 <sup>rd</sup> Rack Available in Four Different Handle Styles	



\* Use & Care manual states "The cutlery rack is best suited for flatware and **most** cooking or serving utensils. **Heavily soiled utensils or items with baked on foods should be placed on the middle rack or spoon basket for best performance.**"



## **Bosch 3rd Rack Competitive Comparison**



\* The RackMatic® feature provides you 9 different positions on the middle rack.

Taller items can be placed anywhere. The rack can be angled to allow for the clearance needed.

Bosch	Feature	Brand "XK"
$\checkmark$	Solid One Piece Design	
√	Deep "V" Design for Large Utensils	
√	Allows 30% More Loading Area	
√	Allows 6" Plate at Highest Setting	
$\checkmark$	Flexibility / Easily Removed	$\checkmark$
$\checkmark$	Silverware Basket Included	$\checkmark$
✓	3 <sup>rd</sup> Rack Available in Four Different Handle Styles	






\* Highest setting of the middle rack obstructs 3<sup>rd</sup> rack from sliding into the dishwasher. You will be unable to place taller items in the middle rack at the highest position.



## **Bosch - RackMatic® 9 Positions of Flexibility**





## **Bosch - Plate Height Capacity using 3 position RackMatic®**

3 position RackMatic® with third rack.



