24" Bar Handle Dishwasher

100 Series - Black SHXM4AY56N





SHXM4AY56N Black

Also available in:

Stainless SHXM4AY55N Steel

Black SHXM4AY54N Stainless

White SHXM4AY52N

Bosch dishwashers are so quiet, you may forget they're on. InfoLight® projects a red light onto the floor to let you know it's running.

Features & Benefits

48 dBA: Quietest dishwasher brand in North America.*

A 3rd rack adds versatility and offers 30% more loading area.**

RackMatic® offers 3 height levels, for 9 possible rack positions. Lower to fit tall glasses above. Raise to fit tall pots below.

24/7 Overflow Protection System® helps prevent water leaks, even when your dishwasher is off.


| General Properties | |
|---------------------------------------|-----------------------------------|
| Number of wash cycles | 5 |
| Number of options | 4 |
| dBA | 48 |
| Drying system | PureDry |
| Third rack | Standard 3rd rack |
| Rack adjustability | 3-Level RackMatic® |
| Tub material | Stainless steel/ polypropylene |
| Control type | Buttons |
| Concealed water heating element | Yes |
| Leak protection system | 24/7 Overflow Protection |
| Water softener | No |
| Five-level wash | Yes |
| ChildLock | No |
| Special features | 3rd rack, InfoLight® |
| Efficiency | |
| Water usage per cycle | 3.2 |
| Energy efficiency class | Tier 1 |
| ENERGY STAR® qualified | Yes |
| Total annual energy consumption (kWh) | 269 |
| Total annual water consumption (g) | 688 |
| Capacity | |
| Number of place settings | 15 |

| Watts (W) | 1440 W |
|--|----------------------------------|
| Current (A) | 12 Amps |
| Volts (V) | 120 V |
| Frequency (Hz) | 60 Hz |
| Power cord length - Install length from corner of unit | 67" |
| | 45" |
| Minimum water pressure (lb/sin) | 15 |
| Length outlet hose (in) | 90 1/2" |
| Dimensions & Weight | |
| Overall appliance dimensions (HxWxD) (in) | 33 7/8" x 23 9/16" x 22 9/16" |
| Required cutout size (HxWxD) (in) | 33 7/8" x 24" x 24" |
| Adjustable feet | Yes |
| Net weight (lbs) | 76 |
| Accessories-Optional | |
| Junction Box | SMZPCJB1UC |
| Dishwasher Drain Hose Extension 76 3/4" | SGZ1010UC |
| Dishwasher Accessory Kit | SGZ1052UC |
| DoubleFlex Silverware Basket | SMZ4000UC |
| Edge Protector | SMZEP001UC |

Technical Details










Accessories: To purchase Bosch accessories, cleaners & parts please visit www.bosch-home.com/us/store or call 1-800-944-2904 (Mon to Fri 5 am to 6 pm PST, Sat 6 am to 3 pm PST).

Notes: All height, width and depth dimensions are shown in inches. BSH reserves the absolute and unrestricted right to change product materials and specifications, at any time, without notice. Consult the product's installation instructions for final dimensional data and other details prior to making cutout.

Warranties: Please see Use & Care manual or Bosch website for statement of limited warranty.

For more information on our entire line of products, go to www.bosch-home.com/us or call 1-800-944-2904







24" Bar Handle Dishwasher


100 Series - Black SHXM4AY56N





Installation Details











Accessories: To purchase Bosch accessories, cleaners & parts please visit www.bosch-home.com/us/store or call 1-800-944-2904 (Mon to Fri 5 am to 6 pm PST, Sat 6 am to 3 pm PST).

Notes: All height, width and depth dimensions are shown in inches. BSH reserves the absolute and unrestricted right to change product materials and specifications, at any time, without notice. Consult the product's installation instructions for final dimensional data and other details prior to making cutout.


Warranties: Please see Use & Care manual or Bosch website for statement of limited warranty.


24" Bar Handle Dishwasher

100 Series - Black SHXM4AY56N



Installation Details





Note: Plumbing installations will vary - refer to local codes. Drain hose included is $90\,^{1}/^{2}$ " (230 cm) and can be extended to a maximum of $168\,^{1}/^{2}$ " (428 cm).

Always use the approved drain hose extension kit (SGZ1010UC).

Ensure a portion of the drain hose is raised between min. 33" (84 cm) and max. 43" (110 cm) above the cabinet floor.

Accessories: To purchase Bosch accessories, cleaners & parts please visit www.bosch-home.com/us/store or call 1-800-944-2904 (Mon to Fri 5 am to 6 pm PST, Sat 6 am to 3 pm PST).

Notes: All height, width and depth dimensions are shown in inches. BSH reserves the absolute and unrestricted right to change product materials and specifications, at any time, without notice. Consult the product's installation instructions for final dimensional data and other details prior to making cutout.